

MOUNTING PROCEDURE

KIT WINDSHIELD TURISM SUZUKI V-STROM '11 - '12

ST6300-11

WWW.BARRACUDAMOTO.COM

KIT

- X1. BARRACUDA WINDSHIELD/SCREEN
- X4. TEFLON WASHERS DIAMETER 5
- X4. RUBBER WASHER
- X2. THICKNESS H 20 MM
- X2. THICKNESS H 13 MM
- X4. SCREW 5X40



REMOVE THE 4 ORIGINAL FIX SCREWS AND ORIGINAL THICKNESS

Thickness mm h 20

INSTALL THE WINDSHIELD/SCREEN USING THE SPECIFIC ALUMINUM THICKNESS AND RUBBER AND TEFLON WASHERS INCLUDED IN THE BARRACUDA INSTALLATION KIT.



Thickness mm h 13

INSTALL THE WINDSHIELD/SCREEN USING THE SPECIFIC ALUMINUM THICKNESS AND RUBBER AND TEFLON WASHERS INCLUDED IN THE BARRACUDA INSTALLATION KIT. PUT THE TEFLON WASHERS UNDER THE HEAD OF SCREWS AND THAN LOCK THE SCREWS OF WINDSHIELD/SCREEN.