



KIT PIPETTE UNIVERSALE PER COMANDO GAS XM2 DOMINO

Il nuovo kit pipette cod. 97.5555.04 per il comando gas XM2 è stato studiato da Domino appositamente per mettere in condizioni l'utente o il meccanico di crearsi le trasmissioni gas ed adattarle alla serie di comandi gas XM2 cod. 5176.03 e 5182.03.

Per l'adattamento di questo kit è consigliabile rivolgersi presso meccanici specializzati ed il loro utilizzo è specifico per attività agonistiche.

KIT OF UNIVERSAL CABLE BENDS FOR DOMINO XM2 THROTTLE CONTROLS

The new kit of cable bends ref. 97.555.04 has been properly studied to enable the end user or the mechanic to make one's throttle cables to fit to Domino XM2 throttle controls ref. 5176.03 and 5182.03.

For the kit fitment it is advisable to go to qualified mechanics.

This kit can be used on tracks and for competitive sport only.



ATTENZIONE

Serrare il barilotto terminale sul filo fino alla rottura calibrata del bullone che avviene alla corretta coppia senza bisogno di attrezzature speciali.

NOTICE

Tighten the nipple on the wire until the bolt breaks at the proper torque and this without using any special tool.



KIT PIPETTE UNIVERSALE PER COMANDO GAS XM2 DOMINO

Il nuovo kit pipette cod. 97.5555.04 per il comando gas XM2 è stato studiato da Domino appositamente per mettere in condizioni l'utente o il meccanico di crearsi le trasmissioni gas ed adattarle alla serie di comandi gas XM2 cod. 5176.03 e 5182.03.

Per l'adattamento di questo kit è consigliabile rivolgersi presso meccanici specializzati ed il loro utilizzo è specifico per attività agonistiche.

KIT OF UNIVERSAL CABLE BENDS FOR DOMINO XM2 THROTTLE CONTROLS

The new kit of cable bends ref. 97.555.04 has been properly studied to enable the end user or the mechanic to make one's throttle cables to fit to Domino XM2 throttle controls ref. 5176.03 and 5182.03.

For the kit fitment it is advisable to go to qualified mechanics.

This kit can be used on tracks and for competitive sport only.



ATTENZIONE

Serrare il barilotto terminale sul filo fino alla rottura calibrata del bullone che avviene alla corretta coppia senza bisogno di attrezzature speciali.

NOTICE

Tighten the nipple on the wire until the bolt breaks at the proper torque and this without using any special tool.